

Assembly Instruction For 21303

- 1. Turn the nipple 1 into the couple 1 then secure by the hex nut 1.
- 2. Attach the cap 1 on the nipple 1 then secure by the hex nut .
- 3. Attach the cap on the nipple 1 then tighten by the loop.
- 4. Turn the nipple 2 into the coupler 2 then secure by the hex nut 2.
- 5.Attach the tube ,tube cover ,glass stator to the nipple 2 then secure by the hex nut 3.
- 6.Attach the glass and cover on the nipple 2 then seucre by hex nut 4.
- 7. Attach the cap 2 to the nipple 2 then secure by the finial.
- 8.Attach the diffuser on the nipple 1 then secure by the balls.

